
















Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Bosch	AQT 33-11		BOADAPTER9
Bosch	AQT 35-12+		BOADAPTER9
Bosch	AQT 37-13+		BOADAPTER9
Bosch	AQT 42-13+		BOADAPTER9
Bosch	AQT 45-14X		BOADAPTER9

Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Clean Force	CF1805		BOADAPTER8
Clean Force	CF1806		BOADAPTER8
Clean Force	CF1807		BOADAPTER8
Gerni	3300		BOADAPTER7
Gerni	3600		BOADAPTER7

Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Gerni	5000		BOADAPTER7
Gerni	5300		BOADAPTER7
Gerni	7000		BOADAPTER7
Gerni	7300		BOADAPTER7
Gerni	115.5		BOADAPTER7






Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Gerni	125.5		BOADAPTER7
Gerni	130.3		BOADAPTER7
Gerni	150.3		BOADAPTER7
Gerni	160.2		BOADAPTER7
Gerni	160.3		BOADAPTER7






Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Karcher	K2		BOADAPTER1
Karcher	K3		BOADAPTER1
Karcher	K4		BOADAPTER1
Karcher	K5		BOADAPTER1
Karcher	K7		BOADAPTER1





Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Michelin	MPX150L		BOADAPTER4
Ryobi	RPW140-G		BOADAPTER9
Ryobi	RPW150-G		BOADAPTER9
Ryobi	RPW-140SC		BOADAPTER9
Ryobi	RPW170-G		BOADAPTER4

Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Ryobi	RPW3600		BOADAPTER6
Stihl	RE88		BOADAPTER7
Stihl	RE109		BOADAPTER7
Stihl	RE119		BOADAPTER7
Stihl	RE129 PLUS		BOADAPTER7

Pressure Washer Adapters

Brand	Model	Picture	Adapter Number
Stihl	RE130 PLUS		BOADAPTER7
Stihl	RE163 PLUS		BOADAPTER2
Workzone (Aldi)	Yellow		BOADAPTER8
Workzone (Aldi)	Titanium (petrol)		BOADAPTER4